

FPLANKEEPER LANYARD KEEPER INSTRUCTIONS

Step 1: Undo Velcro on the lanyard keeper accessory. See figure 1.

Step 2: Locate the existing chest strap keeper on your harness, it may have the breakaway loop completely removed as shown in figure 2 or partially connected only on the one side. If the keeper back plate is completely missing, then the harness must be removed out of service.

Step 3: Locate the chest strap loop that wraps around the shoulder strap, indicated by the yellow circle in figure 2.



Figure 1



Figure 2



Figure 3



Figure 4

Step 4: Pass the Velcro part under the chest strap loop so that the plastic triangle is pointing down as in figure 3.

Step 5: Close the two ends so that the Velcro is connected as in figure 4.

Step 6: Repeat installation of the lanyard keeper on the other side of the harness.

Please don't hesitate to contact us at PIP Canada Ltd if you have any questions.